

Direction indicators.....	51	daily checks.....	204
warning lamp.....	49	deactivating intelligent stop/start.....	93
Disability modifications		DSC active warning lamp.....	47
airbags.....	40	electronic brake force distribution.....	101
Disabling the passenger air bag.....	37	emergency brake assist.....	101
Door mirrors.....	61	forward alert.....	122
blind spot monitor		forward alert warning lamp.....	49
closing vehicle sensing.....	65	gear shift warning lamp.....	49
sensors.....	66	lane departure warning lamp (green).....	48
Door transceiver		lane departure warning lamp (red).....	47
assistance.....	69	low oil pressure.....	46
erase all programming.....	68	park assist limitations.....	112
garage door opener.....	67	park assist troubleshooting.....	113
programming.....	67	rain sensor.....	58
programming a single button.....	68	resume ACC follow mode.....	120
programming the garage door opener.....	67	resume ACC set speed.....	120
rolling code device programming.....	68	running-in.....	204
Double locking.....	13	selecting park assist.....	111
Drive away locking.....	11	sitting correctly.....	19
Drive selector		steep slope control with ABS.....	101
malfunction.....	97	using ACC.....	117
Drive selector fails to elevate.....	97	using cruise control.....	116
Driving		weekly checks.....	204
ACC automatic switch-off.....	119	Driving abroad	
ACC driving hints.....	120	beam pattern.....	53
ACC emergency braking.....	123	headlamps.....	53
ACC follow mode.....	118	Driving aids	
ACC forward alert.....	122	lane departure warning.....	130
ACC gap change.....	118	traffic sign recognition.....	129
ACC malfunction.....	121	Driving position memory.....	19
ACC queue assist.....	119	Driving short distances	
ACC radar detection beam issues.....	121	diesel particulate filter (DPF).....	205
ACC set speed and follow mode		Dual view.....	153
override.....	119	controls.....	153
activating intelligent stop/start.....	93	Dynamic stability control (DSC).....	98
adaptive cruise control.....	117	DSC active warning lamp.....	47
after a collision.....	258	DSC off warning lamp.....	47
arduous conditions.....	204	switching off.....	98
before starting.....	258	switching on.....	98
blind spot monitor		E	
closing vehicle sensing.....	65	Easy route.....	174
blind spot monitor messages.....	66	Eco-data controls.....	94
brake control with ABS.....	101	Effects of battery disconnection.....	229
brakes important information.....	101		