
SWITCHING ON THE IGNITION



E140208

To switch on the ignition without starting the engine:

1. Make sure the brake pedal is not pressed and that a valid Smart key is inside the vehicle.
2. Press and hold the engine **START/STOP** button until the warning lamps illuminate.
3. Release the engine **START/STOP** button.

If the brake pedal is applied when the engine **START/STOP** button is pressed, the engine will start.

ROLLING RE-START

Note: *The engine **START/STOP** button will be inhibited for 2 seconds after the engine has been switched off.*

A rolling restart can be initiated by selecting Neutral (**N**) and pressing the engine **START/STOP** button.

KEYLESS START BACKUP

If the vehicle has been unlocked using the emergency key blade, or the Smart key is not detected by the vehicle, it will be necessary to use the Keyless start backup to disarm the alarm and start the engine.

The Keyless start backup can only be used when the message **Smart Key Not Found - Position As Shown And Press Start Button** is displayed in the Message centre.



E150855

1. Position the Smart key flat against the side of the steering column with the buttons facing outwards.