


MAIN MENU



E153265

- 1. More...:** Displays page 2 of 2 Nav menu screens.
- 2. Cancel guidance:** Cancels the current route guidance.
- 3. Destination entry:** Provides a choice of options for entering a destination.
- 4. Previous destination:** Displays previous destinations entered.
- 5. Display/Hide POI:** Turns the POI (Point of Interest) icons on the map on/off.
- 6.** When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
- 7. Route voice guidance:** Allows the Voice guidance messages to be turned off for the current journey. The soft key is highlighted while Voice guidance is enabled.
- 8.** Quick POI shortcuts: This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation set-up menu.
- 9. Return to map:** Advances to the main map screen.
- 10. Detour:** Allows a detour from the current route.

11. **Nav set-up:** Settings for the Navigation system.
12. **Route options:** Allows selection of various options for the route.
13. **TMC (Traffic Message Channel):** Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
14. **Stored locations:** Manages the stored locations.