
MAIN MENU



1. **More…**: Displays page 2 of 2 Nav menu screens.
2. **Cancel guidance**: Cancels the current route guidance.
3. **Destination entry**: Provides a choice of options for entering a destination.
4. **Previous destination**: Displays previous destinations entered.
5. **Display/Hide POI**: Turns the POI (Point Of Interest) icons on the map on/off.
6. When a destination is set, the Range Rover logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance**: Allows the Voice guidance messages to be turned off for the current journey. The soft key is highlighted while Voice guidance is enabled.
8. Quick POI shortcuts: This provides the option to quickly enter a destination of a local POI. The categories can be changed in the Navigation set-up menu.
9. **Return to map**: Advances to the main map screen.
10. **Detour**: Allows a detour from the current route.

11. **Nav set-up**: Settings for the Navigation system.
12. **Route options**: Allows selection of various options for the route.
13. **TMC** (Traffic Message Channel): Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the journey.
14. **Stored locations**: Manages the stored locations.