

- portable media playing.....181
 - Change a connected phone.....200
 - Changing a bulb.....236
 - Changing a fuse.....251
 - Changing a wheel
 - locking wheel nuts.....277
 - recommended process.....277
 - safety warnings.....274
 - spare wheel.....275
 - temporary spare wheel.....276
 - tool kit.....275
 - Charging the vehicle battery.....249
 - Chassis number.....288
 - Child safety
 - booster seats.....38
 - check list.....34
 - child seats.....33
 - ISOFIX anchor points.....36
 - larger children on booster seats.....38
 - lock and window inhibitor.....33
 - positioning.....35
 - recommended child seats.....35
 - tether straps.....37
 - Cleaning
 - after off-road driving.....237
 - airbag covers.....239
 - exterior.....237
 - interior.....238
 - leather.....239
 - park assist sensors.....237
 - parking aids sensors.....237
 - seat belts.....239
 - sensors and cameras.....237
 - under body.....237
 - Climate control
 - automatic recirculation.....80
 - front.....79
 - fuel burning heater.....82
 - heated and cooled seats.....80
 - rear.....86
 - remote control batteries.....85
 - timed climate.....83
 - timed climate remote controls.....85
 - using the remote control.....84
 - Climate seats.....80
 - Clock.....44
 - Closing the bonnet.....234
 - Closing vehicle sensing.....67
 - Cold weather driving
 - diesel particulate filter (DPF).....233
 - Compact disc.....168
 - Condensation (headlamps).....57
 - Conformity declarations.....222, 301
 - Connecting jump leads.....247
 - Convenience mode.....7
 - Coolant
 - checking the level.....243
 - specification.....243
 - top up.....243
 - Courtesy delay.....56
 - Covers
 - refitting.....235
 - removal.....235
 - Critical warning messages.....50
 - Cruise control.....153
 - ACC driving hints.....157
 - ACC emergency braking.....159
 - ACC follow mode.....154
 - ACC gap change.....155
 - ACC radar detection beam issues.....157
 - ACC set speed and follow mode
 - override.....155
 - adaptive cruise control.....154
 - adaptive cruise control malfunction.....158
 - follow mode.....154
 - forward alert in ACC.....158
 - resume ACC follow mode.....156
 - resume ACC set speed.....156
 - using ACC.....154
 - warning lamp.....54
- ## D
- DAB radio
 - ensembles.....177
 - settings.....176
 - DAB radio controls.....175
 - Data recording.....287
 - Daytime running lamps.....55

- Dealer locations.....215
- Declarations of conformity.....301
 - navigation system.....222
- Deselecting valet mode.....77
- Destination entry.....212
 - postcode.....214
 - search area.....211
- Detection beam issues.....157
- Diesel
 - filler flap.....225
 - fuel.....224
 - glow plugs
 - warning lamp.....51
 - misfuel device.....226
 - sulphur content.....224
 - water in fuel.....226
- Diesel particulate filter (DPF).....232
 - cold weather driving.....233
 - driving short distances.....233
 - sulphur content.....224
- Dimensions.....296
- Direction indicators.....55
 - warning lamp.....53
- Disability modifications
 - airbags.....43
- Disabling the passenger air bag.....41
- Door mirrors.....63
 - blind spot monitor
 - closing vehicle sensing.....67
 - sensors.....68
- Door transceiver
 - assistance.....71
 - erase all programming.....70
 - garage door opener.....69
 - programming.....69
 - programming a single button.....71
 - programming the garage door opener.....69
 - rolling code device programming.....70
- Double locking.....12
 - full alarm.....12
- Downloading from the internet
 - inControl connection.....203
- Drive away locking.....7
- Driver exit
 - deactivating intelligent stop/start.....122
- Driving
 - ACC automatic switch-off.....156
 - ACC driving hints.....157
 - ACC emergency braking.....159
 - ACC follow mode.....154
 - ACC forward alert.....158
 - ACC gap change.....155
 - ACC malfunction.....158
 - ACC queue assist.....156
 - ACC radar detection beam issues.....157
 - ACC set speed and follow mode
 - override.....155
 - activating intelligent stop/start.....121
 - adaptive cruise control.....154
 - after a collision.....287
 - arduous conditions.....232
 - automatic speed limiter.....151
 - before starting.....287
 - blind spot monitor
 - closing vehicle sensing.....67
 - blind spot monitor messages.....68
 - brake control with ABS.....134
 - brakes important information.....134
 - daily checks.....231
 - deactivating intelligent stop/start.....122
 - DSC active warning lamp.....52
 - electronic brake force distribution.....134
 - emergency brake assist.....134
 - forward alert.....158
 - forward alert warning lamp.....54
 - gear shift warning lamp.....53
 - hill start assist.....134
 - intelligent braking.....135
 - lane departure warning lamp (green).....54
 - lane departure warning lamp (red).....51
 - low oil pressure.....50
 - park assist limitations.....147
 - park assist troubleshooting.....148
 - rain sensor.....61
 - resume ACC follow mode.....156
 - resume ACC set speed.....156
 - running-in.....230