Tyre pressure checking after a repair.....272
Tyre pressure monitoring system (TPMS)..267
full size replacements.....268
tyre care.....262
valves.....264
warning lamp.....53
Tyre pressures.....268
Tyre repair kit
checking pressures.....272
repair procedure.....271
safety information.....270
using.....270
Tyres
age degradation.....265
changing.....268
flat spots.....265
full size replacements.....268
important information.....281
Indian regulations.....266
pressure check.....268
pressures.....263
recommended tyre pressure look-up.....268
repair kit.....270
repair kit use.....270
repair procedure.....271
replacements.....264
snow chains.....266
speed ratings.....262
temporary use spare.....268
TPMS.....267
warning lamp.....53
tyre care.....262
tyre repair safety.....270
tyre wall markings.....261
use of spare tyre.....281
valves.....264
vehicle loading.....268
wall markings.....261
winter.....265

U

Under body cleaning.....237
Under bonnet covers.....235
Understeer.....129
Unlocking.....14
all doors.....4
driver's door.....4
entry and exit mode.....27
global opening.....4, 6
keyless entry.....6
mode.....4
multi point entry.....4, 6
opening the tailgate.....7–8
passive entry.....6
single point entry.....4, 6
steering column.....27
Unlocking the steering column.....285
USB devices
connecting multiple devices.....181
Used engine oil.....234
Using adaptive cruise control.....154
Using cruise control.....153
Using the parking aids.....139
Using the spare tyre
important information.....281
Using wheel chocks.....276

V

Valet mode.....77
deselecting.....77
Vehicle alarm.....230
Vehicle battery
battery monitoring system.....249
connecting jump leads.....247
replacing.....249
warning symbols.....247
Vehicle cleaning
after driving off-road.....237
airbag covers.....239
interior.....238
under body.....237
Vehicle data recording.....287
Vehicle loading tyre pressures.....268
Vehicle location
inControl secure.....203
Vehicle recovery
off-road.....285
steering column lock.....7