towing eyes....282
towing on four wheels....285–286
transmission park release....284
transporting the vehicle....285
unlocking the steering column....285
Vehicle storage....231
Vehicle testing on rolling roads....233
Video media player
controls....186
dual view....188
controls....188
headphones....189
full screen view....187
headphones....192
inhibited display....187
rear media touch screen control....190
rear media use....192
VIN number....288
Voice control....194
navigation POI categories....195
recognising your voice....195
settings
command list....77
operating guide....77
preferences....77
voicetags....77
voice training....77
training the system....195
tutorial....195
voicetags....195
Voice guidance....213
Volume
telephone....201

W

Wade sensing
controls....165
Wading depth
touch screen aid....165
Warning lamps....50, 53
ABS....52
ACC follow mode....52
adaptive front lighting system (AFS)....52
airbags....41, 52
automatic speed limiter....52
battery charge....51
brake....50–51
critical warning message....50
cruise control....54
diesel glow plugs....51
DSC active....52
engine/transmission....51
engine temperature....50
external temperature....52
forward alert....54
gear shift warning lamp....53
HDC....53
headlamp high beam....53
high beam assist....53
hybrid vehicle battery fault....51
indicators....53
intelligent stop/start (amber)....53
intelligent stop/start (green)....53
intelligent stop/start (white)....54
lamp test....50
lane departure (green)....54
lane departure (red)....51
low fuel....52
low oil pressure....50
low range selected....54
parking brake....51
rear fog lamps....52
seat belt....51
side lights....53
trailer direction indicators....54
tyre pressure monitoring system (TPMS)....53
Warning messages....46
hybrid vehicles....116
Washer reservoir
capacity....292
Washers....60
fluid specification....245
fluid top up....245
headlamps....61
Water in fuel....226
Web browsing
inControl connection....203

Weights
gross vehicle weights....294
roof load....294
roof rack weight....294
tow ball/hitch....106
towing....106
vehicle weights....294
Wheel changing
important information....281
locking wheel nuts....277
recommended process....277
safety warnings....274
spare wheel....275
temporary spare wheel....276
tilt sensor....277
tool kit....275
use of spare tyre....281
Wheel chocks use....276
Wheels and tyres
age degradation....265
changing a tyre....268
checking the pressures after a repair....272
flat spots....265
full size replacements....268
Indian regulations....266
pressures....263
puncture repair....270
puncture repair safety....270
repair kit....270
repair kit use....270
repair procedure....271
replacements....264
snow chains....266
temporary use spare....268
TPMS....267
TPMS warning lamp....53
tyre care....262
tyre speed ratings....262
tyre wall markings....261
valves....264
winter tyres....265
Wheel spin....129
Wi-Fi
inControl connection....203
Windows
anti-trap protection....73
operation....72
reset....236
side window blinds....73
sunroof reset....236
Winter park position....236
Winter tyres....265
Wipers and washers....60
fluid level....245
rain sensor....61
speed-dependent mode....61
winter park position....62