
AUXILIARY POWER SOCKETS




- 1. Glovebox power socket.
- 2. Front power socket.

- 3. Middle power socket.
- 4. Rear power sockets.

Storage compartments

5. Loadspace power socket.

Executive class rear seats



- 1. Glovebox power socket.
- 2. Front power socket.


- **3.** Front and rear power sockets.
- 4. Middle power socket.

- 5. Loadspace power socket.
- Only use Land Rover approved accessories. Using any other equipment may damage the vehicles's electrical system. If you are in any doubt, contact a Dealer/Authorised Repairer.
- ()

The engine should be running when using accessories for long periods. Failure to do so, can discharge the vehicle's battery.

Note: Power sockets can be used to power approved accessories that use a maximum of 180 Watts.

Long Wheel Base (LWB) vehicles



E161604

- 1. Front power socket.
- 2. Front and rear power sockets.

Note: The illustration shows a rear power socket fitted to a vehicle with Executive class rear seats.

Storage compartments

- **3.** Tablet PC storage power socket.
- 4. Middle power socket.
- 5. Loadspace power socket.
- Only use Land Rover approved accessories. Using any other equipment may damage the vehicle's electrical system. If you are in any doubt, contact a Dealer/Authorised repairer.
- The engine should be running when using accessories for long periods. Failure to do so, can discharge the vehicle's battery.

Note: Power sockets can be used to power approved accessories that use a maximum of 180 Watts.