
USING VOICE CONTROL



Note: *The Voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to your Dealer/Authorised Repairer about testing the Voice System for compatibility with a particular accent group.*

1. Voice button: Press briefly to start a voice session. Press and hold to cancel a voice session.

   Note: *Briefly press the Voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.*
   A voice session will cancel if a high priority warning appears in the Message centre, or there is no user input for a sustained length of time. It is not possible to start a new voice session until the warning has been cleared.

2. Voice symbol: Indicates that a command is available. Wait for the symbol to appear and a tone to sound before using the command.

3. Command list: Appears in the Instrument panel, providing feedback and available commands at each stage of the voice session. Say an available command.

   Note: *As the commands are listed before the system is ready to listen, it is important to wait for the Voice symbol to appear alongside the relevant command, before using the command.*

4. When displayed, say **Cancel** to cancel the current voice session.

5. When displayed, say **Help** to get assistance during a voice session.

   Note: *The currently selected user (**User 1** or **User 2**) is identified at the bottom of the command list.*

   Note: *If a listed item is longer than the available space on the menu, **...>** will appear. Use the Seek controls on the steering wheel to view the entire entry. See **167, AUDIO/VIDEO CONTROLS**.*