

Once any obstructions have been removed, continue the seat movement by pressing the appropriate fold/raise button.

Note: *If no obstructions can be seen, and normal movement cannot be carried out, contact your Dealer/Authorised Repairer.*

INTELLIGENT SEAT CARGO MODE



When requesting a seat to move, make sure that no-one has any body parts in the sweep of the seat, to avoid personal injury.



When requesting a seat to move, make sure that there is no object or obstruction in the sweep of the seat, to avoid vehicle damage.

Intelligent seat cargo mode is used in vehicles with powered front and rear seats. It allows the user to fold and unfold the rear seats, avoiding a clash with the front seats.

If, when folding or unfolding the rear seats, a clash would occur, the front seats move slightly forwards. When folding is complete, the front seats return to the original position or as close as possible, if a clash condition still exists.

After the rear seats begin to fold, they may stop moving to allow the front seats to move to a safe position. Should this occur, keep the buttons pressed or the front seat movement will stop. As soon as the front seats are clear, the rear seats will resume the folding operation.

The front seats only move if the vehicle is stationary.

The driver's seat only moves if the gearbox is in Park (P).

Front seat movement can be cancelled at any time, by pressing any of the front seat switches.