## Wheel changing

## WHEEL CHANGING SAFETY

Before raising the vehicle or changing a wheel, make sure that you read and comply with the following warnings:



Always find a safe place to stop; off the highway and away from traffic.



Make sure that the vehicle and jack are both on firm, level ground. Do not jack the vehicle if it is over a metal grating or manhole cover.



Apply the Electric Parking Brake (EPB), and engage Park (P).



Make sure that the Air suspension is set to Off-road height.



Switch on the hazard warning lamps.



Make sure that the front wheels are in the straight ahead position.



Disconnect any trailer/caravan from the vehicle.



Make sure that all passengers and animals, are out of the vehicle and in a safe place away from the highway.



Place a warning triangle at a suitable distance behind the vehicle; facing towards oncoming traffic.