

- running out.....224
- safety precautions.....223
- tank capacity.....226
- water in fuel.....226
- Fuel burning heater.....82
- Fuel consumption.....228
 - combined cycles.....229
 - extra-urban cycle.....229
 - urban cycle.....228
- Fuel filler flap.....225
- Fuel gauge.....44
- Fuel system.....233
- Fuel tank
 - capacity.....292
- Full screen view for video.....187
- Fuses
 - changing.....251
 - engine compartment fuse box.....252
 - locations.....250
 - luggage compartment fuse box.....257
 - passenger compartment fuse box.....254
- G**
- Garage door opener.....69
 - assistance.....71
 - entry gate.....71
 - erase all programming.....70
 - programming.....69
 - programming a rolling code device.....70
 - programming a single button.....71
- Gearbox
 - automatic.....125
 - emergency park release.....284
 - gear shift warning lamp.....53
 - hill descent.....127
 - limp home mode.....128
 - range change indicators.....127
 - range changing.....127
 - stationary range changing.....127
- General program.....161
- Global closing.....13
- Global opening.....6
- Glow plugs
 - warning lamp.....51
- Gradient release control
 - ascent brake release.....164
- Grass/gravel/snow.....161
- H**
- Handbook symbols.....2
- Handbrake.....135
- Hands free parking.....145
 - park assist limitations.....147
 - park assist troubleshooting.....148
 - selecting park assist.....146
- Headlamps.....55
 - adaptive.....56
 - beam pattern.....57
 - bulb changing.....236
 - condensation.....57
 - courtesy delay.....56
 - daytime running lamps.....55
 - driving abroad.....57
 - high beam assist.....56
 - high beam assist warning lamp.....53
 - high beam warning lamp.....53
 - warning lamp (AFS).....52
 - washers.....61
- Headphones.....189
- Head restraints.....25
 - electric seats.....25–26
- Head up display.....48
- Heated steering wheel.....27
- Heating and ventilation.....79
 - air quality sensor.....80
 - automatic recirculation.....80
 - front.....79
 - fuel burning heater.....82
 - heated and cooled seats.....80
 - rear.....86
 - remote control batteries.....85
 - timed climate.....83
 - timed climate remote controls.....85
 - using the remote control.....84
- High beam assist.....56
- Hill descent control.....163
 - brake release control.....164
 - brake temperature.....164