## CHILD SEAT POSITIONING



Information given within the table is correct at the time of going to press. However, availability of child restraints may change. Please consult your Dealer/Authorised Repairer for the latest recommendation.

**Note:** The information contained in the following table may not be applicable to all countries. If you are in any doubt regarding the type and fitment of child seats, seek advice from a Dealer/Authorised Repairer.



Crash statistics show that children are safest when properly restrained in a child or infant restraint system that is secured in a rear seating position.

**Note:** Ages given are approximate. In case of doubt, the child's weight, not age, should be used when considering an appropriate child seat.

**Note:** The legislation which governs how and where children should be carried when travelling in a vehicle, is subject to change. It is the responsibility of the driver to comply with all regulations in force.

Mass group.	10 kg (22 lb)	0+ = Up to 13 kg (29 lb) 0-18 months	I = 9-18 kg (20-40 lb) 9 months to 4 years	II = 15-25 kg (33-55 lb) 4-9 years	III = 22-36 kg (49-80 lb) 8-12 years
Seating positions					
Front passenger*	U	U	U	U	U
Second row seats	U	U	U	U	U
Third row seats	X	Х	Х	Х	Х



## The third row seating positions are not suitable for child seat groups 0 to III.

- U = Suitable for universal category restraints, approved for this mass group.
- X = not suitable for children in this mass group.
- \* Always make sure that the passenger airbag has been disabled before using a child restraint in this seating position. Adjust the seatback to the upright position, to support the child restraint. If the head restraint has been removed, make sure that it is refitted before the seat is used by a passenger.

## RECOMMENDED CHILD SEATS

Child size/age	Recommended seat	
Groups 0 and 0+	Britax/Römer Baby Safe Plus	
Group I	Britax/Römer Duo Plus	
Group II and III	Britax/Römer Kid Plus	