

6. When the vehicle's **Bluetooth®** wireless technology system is discovered, follow the on-screen instructions. Select **Yes** when prompted, to confirm the pairing. Either the phone or the vehicle system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.
7. Enter the same PIN into the other device.
8. Once your phone is paired and connected to the system, a confirmation message will be displayed before switching to the **Digit dialling** screen.

Note: Due to the duration of a **Bluetooth®** wireless technology device search, it is advised that the *Timeout to home screen feature is switched off, before attempting to search for devices. This setting can be changed within Vehicle, Syst settings, Display set, Timeout to home screen.*

PHONE PAIRING AND CONNECTING USING THE TOUCH SCREEN

1. Switch on your mobile phone's **Bluetooth®** wireless technology device connection. Make sure that your mobile phone is in **Bluetooth®** wireless technology device discoverable mode, sometimes referred to as find me mode (see your phone's operating instructions for more information).
2. Switch the ignition on and make sure the Touch screen is active.
3. From the **Home menu**, select **Phone**.
4. A menu will appear. Select **Search new**.
5. Select the **Vehicle to device** option.
6. Identify your phone from the displayed list and select the corresponding **Pair and connect** option.

Note: If more than 5 phones are detected, it may be necessary to use the scroll bar to see the entire list.
7. When prompted, enter the PIN code into your phone. See your phone's operating instructions for more information.
8. Once your phone is paired and connected to the system, a confirmation message will be displayed, before switching to the Digit dialling screen.

Note: Due to the duration of a **Bluetooth®** wireless technology device search, it is advised that the *Timeout to home screen feature is switched off before attempting to search for devices. This setting can be changed within Vehicle, Syst settings, Display set, Timeout to home screen.*