Warning messages....46
hybrid vehicles....104
Washer reservoir
capacity....283
Washers....60
fluid specification....237
fluid top up....237
headlamps....61
Water in fuel....212
Web browsing
InControl connection....190
Weights
gross vehicle weights....285
roof load....285
roof rack weight....285
tow ball/hitch....94
towing....94
vehicle weights....285
Wheel changing
important information....271
locking wheel nuts....267
recommended process....268
safety warnings....265
spare wheel....265
temporary spare wheel....267
tilt sensor....268
tool kit....265
use of spare tyre....271
Wheel chocks use....267
Wheels and tyres
age degradation....257
changing a tyre....260
checking the pressures after a repair....263
flat spots....256
full size replacements....259
Indian regulations....257
pressures....254
puncture repair....261
puncture repair safety....261
repair kit....261
repair kit use....261
repair procedure....262
replacements....256
snow chains....257
temporary use spare....260
TPMS....258
TPMS warning lamp....53
tyre care....254
tyre speed ratings....254
tyre wall markings....253
valves....256
Wheel spin....118
Wi-Fi
InControl connection....190
Windows
anti-trap protection....73
operation....72
reset....228
sunroof reset....228
Winter park position....228
Wipers and washers....60
fluid level....237
rain sensor....61
speed-dependent mode....61
winter park position....62

# X

Xenon headlamps....224