
ELECTRIC WINDOWS



1. Window switches:

- To open a window: Lightly press the front of the switch and release.
- To close a window: lightly pull the front of the switch up and release.
- One touch open and close: Firmly press or pull the front of the switch and release.

Note: *The windows will operate for 5 minutes after the engine is switched off, as long as none of the doors are opened.*

2. Rear window isolator button.

Note: *This will also isolates rear seat adjustment.*

⚠ **If children are carried in the rear seats, the isolator switch should be used to prevent operation of the windows. If the windows are operated by young children, there is a risk of serious injury or death.**

⚠ **To prevent accidental operation, never leave the Smart key in the vehicle if children or animals are also left in the vehicle.**

3. Panoramic roof blind switch:

- To open the blind in small increments, lightly press the rear of the switch and release.