- To close the blind in small increments, lightly press the front of the switch and release.
- To fully open or close the blind with one touch, firmly press the front or rear of the switch and release.
- 4. Panoramic roof switch:
- Wherever possible, remove any snow, ice, dirt and leaves etc. from the panoramic roof mechanism, before closing. Failure to do so, may damage the panoramic roof mechanism.
- To prevent accidental damage, make sure that any roof rack load will not interfere with the opening of the panoramic roof.
  - To tilt the roof, lightly press the rear of the switch.
  - From the tilt position, lightly press the rear of the switch to open the roof in small increments. To fully open the roof with one touch, firmly press the rear of the switch.
  - To move the roof back to the tilt position in small increments, lightly press the front of the switch. To fully close the roof, press the front of the switch again. To fully close the roof with one touch, firmly press the front of the switch.

**Note:** The panoramic roof will operate for 40 seconds after the ignition is turned off, provided that a front door is not opened.

## ANTI-TRAP PROTECTION



Before closing a window or the sunroof, make sure no occupants have any part of their body in a position where it could be trapped. Even with an anti-trap system, death or serious injury could occur.

Anti-trap protection stops window or sunroof movement if an obstruction or resistance is detected. Check the window or sunroof and its aperture, and remove any obstructions (e.g. ice, etc.).

If it is still necessary to raise the window or close the sunroof, the override procedure is as follows:

- 1. Attempt to close the window/sunroof; Anti-trap will prevent closure and lowers the window/open the sunroof slightly.
- 2. Within ten seconds, attempt to raise the window/close the sunroof again and Anti-trap will prevent closure and lower the window/open the sunroof slightly.
- Attempt to close the window/sunroof for a third time, this time hold the switch in the close position. Hold until closed.

**Note:** If this procedure fails to remove the blockage, the window operation may need to be reset. See **228**, **WINDOW RESET**.

**Note:** The sunroof anti-trap mechanism works differently and does not require reset if activated. See **228**, **SUNROOF RESET**.