Press the button to turn the Heated steering wheel feature on/off. An amber indicator will illuminate when the Heated steering wheel feature is on.

POWER STEERING

A fault with the power steering system is indicated by a message in the Message centre, accompanied by an amber warning lamp (see 50, GENERAL WARNING/INFORMATION MESSAGE (AMBER)).

Power assistance may be reduced to protect the system. This may be required due to overheating, caused by extensive steering inputs or high ambient temperature or both.

Full steering assistance should return when the system has been allowed to cool. If full steering assistance does not return, consult a Land Rover Dealer/Authorised Repairer.