
REAR MEDIA CONTROL FROM THE TOUCH SCREEN



Touch **Rear media** on the **Audio/video** home menu, to select the Rear media control screen.

Note: *When the main Rear media control screen is displayed on the Touch screen, the Rear media remote control is locked out.*

1. Information display.
2. Touch to select the left rear screen.
3. **Sync**: After selecting a source (see items **2** and **4**), touch **Sync** to synchronise both screens. Both screens will then display the selected source.

   Note: *If both screens are already synchronised, the* ***Sync*** *button will be greyed-out.*
4. Touch to select the right rear screen.
5. **Limo Mode**: Touch to turn Limousine mode On and Off.