Rear media

When Limousine mode is turned on, the rear passengers will have total control of the cabin's Audio system and any shared sources via the remote control.

- Lock: Touch to lock or unlock the Rear media remote control.
- 7. **System**: Touch to switch the selected Rear media system on or off.
- 8. Forward/Skip for the selected screen.
- **9.** Touch to play the right rear screen's audio through the vehicle's speaker system.


Note: Only available when the Rear media system is in **Limo mode**.


- **10. Source**: Touch to select the Rear media source selection menu.
- 11. Play/Pause for the selected screen.
- **12.** Touch to play the left rear screen's audio through the vehicle's speaker system.

Note: Only available when the Rear media system is in **Limo mode**.

- 13. Rewind/Skip for the selected screen.
- **14.** Rear media source selection menu: Touch the required media button.
- **15. Source**: Touch to return to the **Rear media** control screen.

REAR MEDIA REMOTE CONTROL





- E151273
- Press and release to turn off the screen. Press and hold to turn off the Rear media system.
- 2. Left screen select.