

## MIRROR DIP WHEN REVERSING

Selecting Reverse (**R**) gear causes the door mirrors to automatically adjust, providing an improved viewing angle for reversing.

The exact dipped position can be adjusted when the mirrors are dipped. The next time Reverse (**R**) gear is selected, the newly adjusted position will be selected.

When the gear selector is moved out of Reverse (**R**), the mirrors will return to their previous position.

**Note:** *If the vehicle's speed exceeds 7 km/h (4 mph) in Reverse (**R**) gear, the mirrors will return to their normal driving position for enhanced visibility.*

The automatic Mirror dip feature can be enabled or disabled using the **Vehicle Set-Up** menu. See **46, INSTRUMENT PANEL MENU**.