

- fuel consumption.....47
- fuel range.....48
- reset.....47
- trip distance.....48
- Turning on the engine
  - active exhaust.....108
- TV
  - controls.....171
  - dual view.....175
  - dual view controls.....175
- Tyre pressure checking after a repair.....263
- Tyre pressure monitoring system (TPMS).....258
  - full size replacements.....259
  - tyre care.....254
  - valves.....256
  - warning lamp.....53
- Tyre pressures.....259
- Tyre repair kit
  - checking pressures.....263
  - repair procedure.....262
  - safety information.....261
  - using.....261
- Tyres
  - age degradation.....257
  - changing.....260
  - flat spots.....256
  - full size replacements.....259
  - important information.....271
  - Indian regulations.....257
  - pressure check.....259
  - pressures.....254
  - recommended tyre pressure look-up.....259
  - repair kit.....261
  - repair kit use.....261
  - repair procedure.....262
  - replacements.....256
  - snow chains.....257
  - speed ratings.....254
  - temporary use spare.....260
  - TPMS.....258
    - warning lamp.....53
  - tyre care.....254
  - tyre repair safety.....261
  - tyre wall markings.....253
  - use of spare tyre.....271
  - valves.....256
  - vehicle loading.....259
  - wall markings.....253
- U**
  - Under body cleaning.....229
  - Under bonnet covers.....221
  - Understeer.....118
  - Unlocking.....14
    - all doors.....4
    - driver's door.....4
    - entry and exit mode.....26
    - global opening.....4, 7
    - keyless entry.....7
    - mode.....4
    - multi point entry.....4, 6
    - opening the tailgate.....8
    - passive entry.....7
    - single point entry.....4, 6
    - steering column.....27
  - Unlocking the steering column.....275
  - USB devices
    - connecting multiple devices.....168
  - Used engine oil.....220
  - Using adaptive cruise control.....141
  - Using cruise control.....140
  - Using the parking aids.....127
  - Using the spare tyre
    - important information.....271
  - Using wheel chocks.....267
- V**
  - Valet mode.....76
    - deselecting.....76
  - Vehicle alarm.....216
  - Vehicle battery
    - battery monitoring system.....241
    - connecting jump leads.....239
    - replacing.....241
    - warning symbols.....239
  - Vehicle cleaning
    - after driving off-road.....229