fuel consumption....47
fuel range....48
reset....47
trip distance....48
Turning on the engine
active exhaust....108
TV
controls....171
dual view....175
dual view controls....175
Tyre pressure checking after a repair....263
Tyre pressure monitoring system (TPMS)..258
full size replacements....259
tyre care....254
valves....256
warning lamp....53
Tyre pressures....259
Tyre repair kit
checking pressures....263
repair procedure....262
safety information....261
using....261
Tyres
age degradation....257
changing....260
flat spots....256
full size replacements....259
important information....271
Indian regulations....257
pressure check....259
pressures....254
recommended tyre pressure look-up....259
repair kit....261
repair kit use....261
repair procedure....262
replacements....256
snow chains....257
speed ratings....254
temporary use spare....260
TPMS....258
warning lamp....53
tyre care....254
tyre repair safety....261
tyre wall markings....253
use of spare tyre....271
valves....256
vehicle loading....259
wall markings....253

U

Under body cleaning....229
Under bonnet covers....221
Understeer....118
Unlocking....14
all doors....4
driver's door....4
entry and exit mode....26
global opening....4, 7
keyless entry....7
mode....4
multi point entry....4, 6
opening the tailgate....8
passive entry....7
single point entry....4, 6
steering column....27
Unlocking the steering column....275
USB devices
connecting multiple devices....168
Used engine oil....220
Using adaptive cruise control....141
Using cruise control....140
Using the parking aids....127
Using the spare tyre
important information....271
Using wheel chocks....267

V

Valet mode....76
deselecting....76
Vehicle alarm....216
Vehicle battery
battery monitoring system....241
connecting jump leads....239
replacing....241
warning symbols....239
Vehicle cleaning
after driving off-road....229