

- fuel consumption.....47
 - fuel range.....48
 - reset.....47
 - trip distance.....48
 - Turning on the engine
 - active exhaust.....108
 - TV
 - controls.....171
 - dual view.....175
 - dual view controls.....175
 - Tyre pressure checking after a repair.....263
 - Tyre pressure monitoring system (TPMS).....258
 - full size replacements.....259
 - tyre care.....254
 - valves.....256
 - warning lamp.....53
 - Tyre pressures.....259
 - Tyre repair kit
 - checking pressures.....263
 - repair procedure.....262
 - safety information.....261
 - using.....261
 - Tyres
 - age degradation.....257
 - changing.....260
 - flat spots.....256
 - full size replacements.....259
 - important information.....271
 - Indian regulations.....257
 - pressure check.....259
 - pressures.....254
 - recommended tyre pressure look-up.....259
 - repair kit.....261
 - repair kit use.....261
 - repair procedure.....262
 - replacements.....256
 - snow chains.....257
 - speed ratings.....254
 - temporary use spare.....260
 - TPMS.....258
 - warning lamp.....53
 - tyre care.....254
 - tyre repair safety.....261
 - tyre wall markings.....253
 - use of spare tyre.....271
 - valves.....256
 - vehicle loading.....259
 - wall markings.....253
- ## U
- Under body cleaning.....229
 - Under bonnet covers.....221
 - Understeer.....118
 - Unlocking.....14
 - all doors.....4
 - driver's door.....4
 - entry and exit mode.....26
 - global opening.....4, 7
 - keyless entry.....7
 - mode.....4
 - multi point entry.....4, 6
 - opening the tailgate.....8
 - passive entry.....7
 - single point entry.....4, 6
 - steering column.....27
 - Unlocking the steering column.....275
 - USB devices
 - connecting multiple devices.....168
 - Used engine oil.....220
 - Using adaptive cruise control.....141
 - Using cruise control.....140
 - Using the parking aids.....127
 - Using the spare tyre
 - important information.....271
 - Using wheel chocks.....267
- ## V
- Valet mode.....76
 - deselecting.....76
 - Vehicle alarm.....216
 - Vehicle battery
 - battery monitoring system.....241
 - connecting jump leads.....239
 - replacing.....241
 - warning symbols.....239
 - Vehicle cleaning
 - after driving off-road.....229