

RECALLING A PREVIOUS DESTINATION

1. From the **Nav menu**, touch **Previous destination**.
2. Touch your previous destination from the list. The map showing the selected destination is displayed.
3. Touch **GO** to start the journey.

MOTORWAY ENTRY/EXIT

1. From the **Nav menu**, touch **Destination entry**.
2. Touch **More....**
3. Touch **Motorway Entry/Exit**.
4. Enter the motorway name or number, or select from **List**.
5. Touch **Entrance** or **Exit**.
6. Enter the entrance or exit name for the chosen motorway, or select from **List**. The map showing the selected motorway and junction is displayed.
7. Touch **GO** to start the journey.

POINTS OF INTEREST (POI)

1. From the **Nav menu**, touch **Destination entry**.
2. Touch **More....**
3. Touch **Point of interest**.
4. Touch **POI name** and touch **Ok** to confirm.
5. Enter the POI name or select from **List**.
6. Alternatively, choose **Category** to see all of the categories of POI and make your selection. See **202, CATEGORIES AND SUB-CATEGORIES**.
7. To narrow the search area, touch **Town** to enter a town name.
8. Once the POI has been selected, the map showing the selected destination is displayed.
9. Touch **GO** to start the journey.

Note: If entering a POI name results in too many matches being listed, try entering the town name first. If you do not know the name of the POI you want, try selecting a POI category.

Note: POI icons can only be displayed up to the 1 km (½ mile) zoom level.

DEALER LOCATIONS

Details of Land Rover Dealers are held on the Navigation system as a Point Of Interest (POI) category, under car/automotive category. See **203, LOCAL POI SEARCH**.

CATEGORIES AND SUB-CATEGORIES

The POI database is divided into a number of categories. Each main category is further divided into a number of sub-categories.

Touch the desired category and then choose the desired sub-categories.