## **Navigation system**

# RECALLING A PREVIOUS DESTINATION

- From the Nav menu, touch Previous destination.
- Touch your previous destination from the list. The map showing the selected destination is displayed.
- 3. Touch **GO** to start the journey.

#### **MOTORWAY ENTRY/EXIT**

- 1. From the Nav menu, touch Destination entry.
- 2. Touch More....
- 3. Touch Motorway Entry/Exit.
- Enter the motorway name or number, or select from List.
- 5. Touch Entrance or Exit.
- Enter the entrance or exit name for the chosen motorway, or select from List. The map showing the selected motorway and junction is displayed.
- 7. Touch **GO** to start the journey.

## **POINTS OF INTEREST (POI)**

- 1. From the Nav menu, touch Destination entry.
- 2. Touch More....
- 3. Touch Point of interest.
- 4. Touch POI name and touch Ok to confirm.
- 5. Enter the POI name or select from List.
- Alternatively, choose Category to see all of the categories of POI and make your selection. See 202, CATEGORIES AND SUB-CATEGORIES.
- **7.** To narrow the search area, touch **Town** to enter a town name.
- **8.** Once the POI has been selected, the map showing the selected destination is displayed.
- 9. Touch **GO** to start the journey.

**Note:** If entering a POI name results in too many matches being listed, try entering the town name first. If you do not know the name of the POI you want, try selecting a POI category.

**Note:** POI icons can only be displayed up to the 1 km (½ mile) zoom level.

## **DEALER LOCATIONS**

Details of Land Rover Dealers are held on the Navigation system as a Point Of Interest (POI) category, under car/automotive category. See **203**, **LOCAL POI SEARCH**.

### **CATEGORIES AND SUB-CATEGORIES**

The POI database is divided into a number of categories. Each main category is further divided into a number of sub-categories.

Touch the desired category and then choose the desired sub-categories.