


Your vehicle is equipped with anchorage points on the back of the second row seat frames. These should be used to attach straps from child seats or restraint systems.

- Install the child restraint securely in one of the rear seating positions.
- Pass the tether strap over the seatback and beneath the head restraint for the outer seat positions.

  Note: *For the centre seat position, pass the tether strap over the fixed head restraint.*
- Attach the tether strap hook to the tether anchor point on the back of the seat. Make sure that the tether strap hook is facing the correct way (see illustration).
- Tighten the tether strap, according to the child restraint manufacturer's instructions.

BOOSTER SEATS

In a situation where a child is too large to fit into a child safety seat but is still too small to safely use just the 3 point belt, a booster seat is recommended for maximum safety. Follow the manufacturer's instructions for fitting and use, then adjust the seat belt to suit. See **35, CHILD SEAT POSITIONING**.

The vehicle's head restraint may need to be removed to accommodate all adjustments of the child restraint. See **24, HEAD RESTRAINT REMOVAL**.