Entering the vehicle

Object detection while closing: If an object is detected that would interfere with the tailgate closing, tailgate movement will stop and then reverse to the fully open position (if available to do so). An audible warning will be given to indicate a mislock. Remove any obstructions and if the tailgate is open, press the tailgate switch again to close the tailgate. If the tailgate is not open, press a tailgate release switch to open the tailgate, remove any obstructions. Once the obstructions have been removed, press the tailgate close switch to close the tailgate.

Instructional video - Powered tailgate.



E166648

TAILGATE OPENING HEIGHT

The maximum opening height can be set as required. This is useful in parking areas with low ceiling heights, or just for ease of use.

- 1. Open the tailgate to the position which you want to set as the maximum height. Press any tailgate control to stop movement at the required position. The final position can be achieved manually, if required.
- 2. Make sure the tailgate is stationary for at least 3 seconds.
- **3.** Press and hold the tailgate close switch for 10 seconds to set the maximum opening height.
- 4. Close the tailgate, then open again to check that it opens to the programmed height.

Note: If, after performing part **3** of the process, the tailgate closes automatically, the required height has not been set. Repeat the process, making sure that all steps are adhered to.

To reset the maximum opening height, repeat the process, but when the tailgate reaches its current programmed height, manually move it to the fully open position, before pressing and holding the button.

The powered tailgate may lose its position memory if there are multiple object detections, or if the battery voltage is low. Powered operation may be inhibited.

To reset the tailgate:

- 1. Manually close the tailgate.
- 2. Press a release switch.
- **3.** Allow the tailgate to power fully open, or to the previously set position.
- 4. Press and release the close switch.
- Allow the tailgate to power close fully. The tailgate's programmed memory will now be restored.