
## **STORAGE COMPARTMENTS**



- 1. Under seat storage tray: To access the tray, lift the handle to release and then pull forwards. Note, there is a tray under each front seat.
- ① Do not exceed the maximum storage weight of 1.5 kg (3 lbs).
- 2. Bag hook.
- 3. Glovebox: Pull the handle to open.
- **4.** Armrest and cubby box: Pull the release lever and then raise the armrest to access the storage area.

## Storage compartments



To avoid personal injury, keep hands and fingers clear from the front and rear edges of the armrest during the opening and closing of the cubby box.

**5.** Cup holders: Slide back the cover to reveal the cup holders.



Do not drink, or use the drinks holders when driving.

- **6.** Rear armrest storage and cup holders: Press the release button to access the storage compartment.
- 7. Storage areas.



Make sure that any items stored in the vehicle are secure and cannot move. If the vehicle is involved in an accident, or subject to a sudden braking or direction change, loose items can cause serious injury.