

- Fuel system.....190
- Fuel tank
 - capacity.....250
- Fuses
 - changing.....211
 - engine compartment fuse box.....212
 - locations.....210
 - luggage compartment fuse box.....216
 - passenger compartment fuse box.....214
- G**
- Garage door opener.....74
 - assistance.....76
 - entry gate.....75
 - erase all programming.....75
 - programming.....74
 - programming a rolling code device.....75
 - programming a single button.....75
- Gearbox
 - automatic.....112
 - drive selector fails to elevate.....114
 - emergency park release.....241
 - fault.....114
 - gear shift warning lamp.....56
 - manual.....114
- General program.....142
- Glass cleaning.....198
- Global closing.....16
- Global opening.....8
- Glow plugs
 - warning lamp.....55
- Gradient release control
 - ascent brake release.....145
- Grass/gravel/snow.....142
- H**
- Handbook symbols.....2
- Handbrake.....120
- Hands free parking.....126
 - park assist limitations.....128
 - park assist troubleshooting.....129
 - selecting park assist.....127
- Headlamps.....58
 - adaptive.....60
 - beam pattern.....60
 - bulb changing.....190, 194
 - bulb specification.....254
 - condensation.....60
 - courtesy delay.....59
 - daytime running lamps.....59
 - driving abroad.....60
 - high beam assist.....59
 - high beam assist warning lamp.....56
 - high beam warning lamp.....57
 - levelling.....60
 - removal.....192
 - warning lamp (AFS).....55
 - washers.....66
 - xenon.....191
- Head restraints
 - front seats.....29
 - rear seats.....29
- Head up display.....51
- Heated exterior mirrors.....69
- Heated seats.....85
- Heated steering wheel.....31
- Heating and ventilation.....82–83
 - air vents.....84
 - auto setting.....83
 - heated and cooled seats.....85
 - heated seats.....85
 - manual.....82
 - remote control batteries.....87
 - third row seats.....88
- High beam assist.....59
- Hill descent control.....144
 - brake release control.....145
 - brake temperature.....145
 - warning lamp.....56
- Hitch guidance cameras.....96
- Homelink.....74
 - assistance.....76
 - erase all programming.....75
 - gate/door opener.....75
 - programming.....74
 - programming a single button.....75
 - programming the garage door opener.....74