


## MEDIA CONTROLS



E164011



**In the interest of safety, only operate, adjust or view the system when it is safe to do so.**



**Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.**

1. Press to select the **RADIO** menu screen or the media screen for the last selected media source.
2. Media source: Press to select the media source list. Touch the required media source from the list:
  - **FM Radio**
  - **AM Radio**
  - **DAB Radio**
  - **Bluetooth\***
  - **USB\***

- **iPod\***
- **AUX**

**Note:** \*Only a connected portable media or **Bluetooth®** device will appear on the Source list. Therefore, before selecting a device, the source media device has to be connected or paired (Bluetooth) to the vehicle.

3. Press to select the **Media** system.
4. Touch to select the **General settings** menu screen. For the audio settings, select **Audio**. See **151, AUDIO SETTINGS**.
5. Press to switch the Audio system on/off, rotate to adjust the volume level.

**Note:** The Media system will operate with the ignition on or off, but will switch off when the ignition is switched off. Switch the Media system on again, if required.