


MEDIA CONTROLS



E164011



In the interest of safety, only operate, adjust or view the system when it is safe to do so.



Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.

1. Press to select the **RADIO** menu screen or the media screen for the last selected media source.
2. Media source: Press to select the media source list. Touch the required media source from the list:
 - **FM Radio**
 - **AM Radio**
 - **DAB Radio**
 - **Bluetooth***
 - **USB***

- **iPod***
- **AUX**

Note: *Only a connected portable media or **Bluetooth®** device will appear on the Source list. Therefore, before selecting a device, the source media device has to be connected or paired (Bluetooth) to the vehicle.

3. Press to select the **Media** system.
4. Touch to select the **General settings** menu screen. For the audio settings, select **Audio**. See **151, AUDIO SETTINGS**.
5. Press to switch the Audio system on/off, rotate to adjust the volume level.

Note: The Media system will operate with the ignition on or off, but will switch off when the ignition is switched off. Switch the Media system on again, if required.