

- sitting correctly.....21
- steep slope control with ABS.....118
- using ACC.....134
- using cruise control.....133
- weekly checks.....185
- Driving abroad
  - beam pattern.....60
  - headlamps.....60
- Driving aids
  - lane departure warning.....148
  - traffic sign recognition.....147
- Driving position memory.....21
- Driving programs
  - dynamic program.....142
  - general program.....142
  - grass/gravel/snow.....142
  - mud/ruts.....142
  - override options.....143
  - sand.....142
  - system difficulties.....143
- Driving short distances
  - diesel particulate filter (DPF).....186
- Dynamic program.....142
- Dynamic stability control (DSC).....115
  - DSC active warning lamp.....54
  - DSC off warning lamp.....55
  - switching off.....115
  - switching on.....115
- E**
- Eco program
  - fuel saving.....141
- Effects of battery disconnection.....209
- Electric parking brake.....120
- Electric seats.....20
  - position memory.....21
  - restricted front seat travel.....21
- Electric windows
  - operation.....77
- Electronic brake force distribution.....118
- Electronic data.....245
- Electronic traction control (ETC).....116
- Email
  - InControl connection.....166
- Emergency (navigation).....174
- Emergency brake assist.....118, 139
- Emergency call
  - InControl link.....165
- Emergency key locking.....17
- Engine
  - antifreeze level.....203
  - compartment opening.....188
  - coolant level.....203
  - diesel fuel.....180
  - diesel particulate filter (DPF).....186
  - engine compartment
    - poisonous fluids.....188
  - oil level.....201
  - petrol fuels.....179
  - running-in.....185
  - specifications.....247
  - starting
    - keyless start backup.....109
    - switching off.....108
- Engine/transmission warning lamp.....54
- Engine compartment
  - fluid filler locations.....201
- Engine covers
  - refitting.....189
  - removal.....189
- Engine oil
  - capacity.....250
- Engine starting.....108
- Entering the vehicle
  - entry and exit mode.....22
  - global opening.....8
  - keyless entry.....8
  - passive entry.....8
  - unlocking mode.....8
  - unlocking the steering column.....31
- Ethanol.....179
- Event data recording.....245
- Exhaust emissions.....190
- Exiting the vehicle
  - arming the alarm.....17
  - closing mislock.....17
  - door locks and release levers.....16
  - double locking.....14