

- sitting correctly.....21
- steep slope control with ABS.....118
- using ACC.....134
- using cruise control.....133
- weekly checks.....185
- Driving abroad
 - beam pattern.....60
 - headlamps.....60
- Driving aids
 - lane departure warning.....148
 - traffic sign recognition.....147
- Driving position memory.....21
- Driving programs
 - dynamic program.....142
 - general program.....142
 - grass/gravel/snow.....142
 - mud/ruts.....142
 - override options.....143
 - sand.....142
 - system difficulties.....143
- Driving short distances
 - diesel particulate filter (DPF).....186
- Dynamic program.....142
- Dynamic stability control (DSC).....115
 - DSC active warning lamp.....54
 - DSC off warning lamp.....55
 - switching off.....115
 - switching on.....115
- E**
- Eco program
 - fuel saving.....141
- Effects of battery disconnection.....209
- Electric parking brake.....120
- Electric seats.....20
 - position memory.....21
 - restricted front seat travel.....21
- Electric windows
 - operation.....77
- Electronic brake force distribution.....118
- Electronic data.....245
- Electronic traction control (ETC).....116
- Email
 - InControl connection.....166
- Emergency (navigation).....174
- Emergency brake assist.....118, 139
- Emergency call
 - InControl link.....165
- Emergency key locking.....17
- Engine
 - antifreeze level.....203
 - compartment opening.....188
 - coolant level.....203
 - diesel fuel.....180
 - diesel particulate filter (DPF).....186
 - engine compartment
 - poisonous fluids.....188
 - oil level.....201
 - petrol fuels.....179
 - running-in.....185
 - specifications.....247
 - starting
 - keyless start backup.....109
 - switching off.....108
- Engine/transmission warning lamp.....54
- Engine compartment
 - fluid filler locations.....201
- Engine covers
 - refitting.....189
 - removal.....189
- Engine oil
 - capacity.....250
- Engine starting.....108
- Entering the vehicle
 - entry and exit mode.....22
 - global opening.....8
 - keyless entry.....8
 - passive entry.....8
 - unlocking mode.....8
 - unlocking the steering column.....31
- Ethanol.....179
- Event data recording.....245
- Exhaust emissions.....190
- Exiting the vehicle
 - arming the alarm.....17
 - closing mislock.....17
 - door locks and release levers.....16
 - double locking.....14