


To prevent malfunction of the airbag system always consult your Dealer/Authorised Repairer before fitting any of the following:

- Electronic equipment such as a mobile phone, 2-way radio or in-car entertainment system.
- Accessories attached to the front of the vehicle.
- Any modification to the front of the vehicle.
- Any modification involving the removal or repair of any wiring or component in the vicinity of any of the airbag system components, including the steering wheel, steering column, instrument or fascia panels.
- Any modification to the fascia panels or steering wheel.

## PARTS AND ACCESSORIES

 The fitting of non-approved parts and accessories, or the carrying out of non-approved alterations or conversions, may be dangerous and could affect the safety of the vehicle and occupants and also invalidate the terms and conditions of the vehicle warranty.

 Jaguar Land Rover Limited will not accept any liability for death, personal injury or damage to property which may occur as a direct result of fitment of non-approved accessories or the carrying out of non-approved conversions to Land Rover vehicles.

 All replacement parts for the air conditioning system should be new and equivalent to the manufacturer's original equipment while complying with the SAE Standards. Contact a Dealer/Authorized Repairer for advice.





This symbol may be used on an under bonnet label and is relevant to the air conditioning refrigerant fluid. The symbol identifies extremely flammable chemicals that have an extremely low flash point and boiling point, and gases that catch fire in contact with air.


## ROAD TESTING DYNAMOMETERS (ROLLING ROADS)


It is essential that any dynamometer testing is carried out only by a qualified person, familiar with the dynamometer testing and safety procedures practised by Dealers/Authorised Repairers.

## SAFETY IN THE GARAGE

 If the vehicle has been driven recently, do not touch exhaust and cooling system components until the engine has cooled.

 Never leave the engine running in an unventilated area - exhaust gases are poisonous and extremely dangerous.

 Never work or allow any person to place any part of their body beneath a vehicle supported by a jack.

 Keep your hands and clothing away from drive belts, pulleys and fans. Some fans may continue to operate after the engine has stopped. They may also start to operate after the engine is turned off and continue operating for up to 10 minutes.

 Remove metal wristbands and jewellery, before working in the engine compartment.