


## AUTOMATIC CLIMATE CONTROL



E164172

**Note:** The Climate control system removes moisture from the air and deposits the excess water beneath the vehicle. Puddles may form, but this is normal and is no cause for concern.

**Note:** The LED indicator lamps, above the switches, will illuminate when the function is selected.

**Note:** When the ECO program is selected, heating and ventilation settings are automatically adjusted to reduce energy consumption. See **141, ECO PROGRAM**.

1. **Climate:** To access the **FRONT CLIMATE** screen, touch **Climate** on the **HOME** menu screen. See **79, TOUCH SCREEN CONTROLS**.
2. **Front Seats:** Touch to select the **Climate seats** settings screen.
3. **Rear A/C:** Touch to select the settings screen for the third row seats Climate control. See **88, CLIMATE CONTROL FOR THIRD ROW SEATS**.
4. **Timed Climate:** Touch to select the **TIMED CLIMATE** settings menu. See **86, TIMED CLIMATE**.