


AUTOMATIC CLIMATE CONTROL



E164172

Note: The Climate control system removes moisture from the air and deposits the excess water beneath the vehicle. Puddles may form, but this is normal and is no cause for concern.

Note: The LED indicator lamps, above the switches, will illuminate when the function is selected.

Note: When the ECO program is selected, heating and ventilation settings are automatically adjusted to reduce energy consumption. See **141, ECO PROGRAM**.

1. **Climate:** To access the **FRONT CLIMATE** screen, touch **Climate** on the **HOME** menu screen. See **79, TOUCH SCREEN CONTROLS**.
2. **Front Seats:** Touch to select the **Climate seats** settings screen.
3. **Rear A/C:** Touch to select the settings screen for the third row seats Climate control. See **88, CLIMATE CONTROL FOR THIRD ROW SEATS**.
4. **Timed Climate:** Touch to select the **TIMED CLIMATE** settings menu. See **86, TIMED CLIMATE**.