
Storage compartments

AUXILIARY POWER SOCKETS



There are 12V power sockets and 5V USB charge sockets fitted to this vehicle.

Remove the cover to access a 12V power socket.

Note: The 12V power sockets can be used to power approved accessories that use a maximum of 120 Watts.

Lift the cover to access a 5V USB charge socket. 12V and 5V socket locations:

- 12V power socket, located on the centre console. Depending on the vehicle specification, a 5V USB charge socket may be fitted.
- 2. 5V USB charge socket, located on the passenger side fascia.
- **3.** 12V power socket, located inside the front centre console cubby box.
- **4.** 5V USB charge socket, located on the rear of the centre console.
- **5.** 5V USB charge socket, located in the loadspace on vehicles with third row seats.

Note: Not fitted if the vehicle has the third row seat air conditioning control.

- **6.** 12V power socket, located in the loadspace.
- 7. 5V USB charge socket, located in the loadspace on vehicles with third row seats.
- **8.** 12V power socket, located on the rear of the centre console.
- **9.** 5V USB charge socket or 12V power socket, located on the rear of the centre console.

Note: Socket locations are dependent on the specification of the vehicle.

- Only use Land Rover approved accessories. Using any other equipment may damage the vehicle's electrical system and/or cause the battery to discharge. If you are in any doubt, contact a Dealer/Authorised Repairer.
- The engine should be running when using accessories for long periods. Failure to do so can discharge the battery.