
## Voice control

## **USING VOICE CONTROL**

Note: The Voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to a Dealer/Authorised Repairer about testing the Voice system for compatibility with a particular accent group.

**Note:** The Voice system will not operate unless the SD card supplied with the vehicle is inserted correctly into the SD card slot. See **155**, **CONNECTING A MEDIA DEVICE**.



To start a voice session, briefly press the voice button on the steering wheel. The **Teleprompter list** appears on the Touch screen. To cancel a voice session, press and hold the voice button.

**Note:** Briefly press the voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.

Teleprompter list: This list provides feedback and available commands for each stage of the voice session.



Voice symbol: This indicates that a command is available. Wait for the symbol to appear and a tone to sound before saying a command.

**Note:** As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear, before saying a command.

Say **Cancel** (at any time) to cancel the current voice command.

## **NAVIGATION POI VOICE COMMANDS**

To request the display of Points Of Interest (POIs), say **Find next** with 1 of the following POI categories:

- Find next (Petrol station/Petrol).
- Find next (Parking/Car park).
- Find next (Land Rover [Dealer]).
- Find next (Hospital).
- Find next (Golf course).
- Find next (Tourist information office).
- Find next (Restaurant).
- Find next (Shopping centre).
- Find next (Hotel/Motel).
- Find next (say a Brand name) of the POI category.

**Note:** The word **Find next** must be followed immediately by a category.