


USING VOICE CONTROL

Note: The Voice system has been designed to recognise a number of languages. However, Land Rover cannot guarantee the system will be compatible with every accent group within those languages. Please speak to a Dealer/Authorised Repairer about testing the Voice system for compatibility with a particular accent group.

Note: The Voice system will not operate unless the SD card supplied with the vehicle is inserted correctly into the SD card slot. See **155**, **CONNECTING A MEDIA DEVICE**.



To start a voice session, briefly press the voice button on the steering wheel. The **Teleprompter list** appears on the Touch screen. To cancel a voice session, press and hold the voice button.

Note: Briefly press the voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.

Teleprompter list: This list provides feedback and available commands for each stage of the voice session.



Voice symbol: This indicates that a command is available. Wait for the symbol to appear and a tone to sound before saying a command.

Note: As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear, before saying a command.

Say **Cancel** (at any time) to cancel the current voice command.

NAVIGATION POI VOICE COMMANDS

To request the display of Points Of Interest (POIs), say **Find next** with 1 of the following POI categories:

- **Find next (Petrol station/Petrol).**
- **Find next (Parking/Car park).**
- **Find next (Land Rover [Dealer]).**
- **Find next (Hospital).**
- **Find next (Golf course).**
- **Find next (Tourist information office).**
- **Find next (Restaurant).**
- **Find next (Shopping centre).**
- **Find next (Hotel/Motel).**
- **Find next** (say a Brand name) of the POI category.

Note: The word **Find next** must be followed immediately by a category.