

Index

Auxiliary device connection.....155, 158
Auxiliary power sockets.....91

B

Battery

boost starting.....208
care.....206
charging.....208
connecting jump leads.....207
disconnection.....209
effects of disconnection.....209
maintenance.....206
monitoring system.....209
removing.....208
replacing.....208
using a starting aid.....208
warning lamp.....54
warning symbols.....206

Battery backed sounder.....16

Blinds

rear window.....77
side windows.....77

Blind spot monitor

closing vehicle sensing.....72
displayed messages.....73
sensor blockage.....73

Bluetooth

changing the connected phone or
device.....162
deleting the connected phone.....162
general information.....161
pairing and connecting a device.....158
pairing a wireless technology device.....161
phone compatibility.....161
telephone
overview.....163
safety.....164

Bonnet

closing.....188
opening.....188

Booster seats for larger children.....39

Boost starting.....208

Brakes

ABS warning lamp.....55

automatic braking.....119
control with ABS.....118
electronic brake force distribution.....118
emergency assist.....139
emergency brake assist.....118
fluid

specification.....205
top up.....205
fluid level.....204
handbrake.....120
important information.....118
parking brake warning lamp.....53
steep slope control.....118
warning lamp (amber).....54
warning lamp (red).....53

Brake temperature.....145

Bulbs

changing a bulb.....190
direction indicator.....194–195
reversing lamp.....195
specification.....254

C

Call volume.....164

Cameras

hitch guidance.....96
proximity view.....130
rear camera.....123, 125
reverse traffic detection.....125
touch screen menu.....130

Capacities.....250

engine oil.....250
fuel tank.....250
washer reservoir.....250

Changing a bulb.....190

Changing a fuse.....211

Changing a wheel

locking wheel nuts.....237
recommended process.....237
safety warnings.....233
spare wheel.....234
temporary spare wheel.....237
tool kit.....233

Changing the connected phone or device...162