

## MIRROR DIP WHEN REVERSING

If the vehicle is equipped with memory seats, when Reverse (**R**) is selected, the door mirrors can be set to automatically adjust, providing an improved viewing angle of the kerb side for reversing.

The automatic mirror dip feature can be enabled or disabled using the **Vehicle Set-up** menu. See **49, INSTRUMENT PANEL MENU**.

The exact dipped position can be adjusted while the mirrors are dipped:

1. With the ignition on, select Reverse (**R**).
2. With the mirror adjust controls, adjust to the desired dip position.
3. Select Neutral (**N**). This will store your setting for future use.

The next time Reverse (**R**) is selected, the newly adjusted position will be selected.

When the gear selector is moved out of Reverse (**R**), the mirrors will return to their previous position.

**Note:** *If the vehicle's speed exceeds 7 km/h (4 mph) in Reverse (**R**), the mirrors will return to their normal driving position for enhanced visibility.*

## HEATED MIRRORS

The rear-view door mirror heaters operate automatically according to the external temperature and windscreen wiper operation.