

- Charging the vehicle battery.....208
 - Chassis number.....246
 - Child safety
 - booster seats.....39
 - check list.....39
 - child seats.....36
 - ISOFIX installation.....39
 - larger children on booster seats.....39
 - lock and window inhibitor.....36
 - positioning.....37
 - recommended child seats.....39
 - tether straps.....40
 - Cleaning
 - after off-road driving.....197
 - airbag covers.....199
 - alloy wheels.....198
 - exterior.....197
 - glass.....198
 - interior.....198
 - leather.....198
 - park assist sensors.....197
 - parking aids sensors.....197
 - rear screen.....198
 - seat belts.....199
 - sensors and cameras.....197
 - under body.....197
 - washer jets.....200
 - Climate control
 - air vents.....84
 - auto setting.....83
 - heated and cooled seats.....85
 - heated seats.....85
 - manual.....82
 - remote control batteries.....87
 - third row seats.....88
 - Climate seats.....85
 - Clock.....48
 - Closing the bonnet.....188
 - Closing vehicle sensing.....72
 - Clutch
 - fluid level.....204
 - Cold weather driving
 - diesel particulate filter (DPF).....186
 - Compatibility of phones.....161
 - Condensation (headlamps).....60
 - Conformity declarations.....258
 - Connecting a media device.....155
 - Connecting a phone or device.....161
 - Connecting jump leads.....207
 - Connecting multiple portable media devices.....158
 - Controls
 - touch screen.....79
 - Convenience mode.....9
 - Coolant
 - checking the level.....203
 - specification.....203
 - top up.....203
 - Courtesy delay.....59
 - Covers
 - refitting.....189
 - removal.....189
 - Critical warning messages.....53
 - Cruise control.....133
 - ACC driving hints.....137
 - ACC emergency braking.....140
 - ACC follow mode.....135
 - ACC gap change.....135
 - ACC radar detection beam issues.....138
 - ACC set speed and follow mode override.....136
 - adaptive cruise control.....134
 - adaptive cruise control malfunction.....138
 - follow mode.....135
 - forward alert in ACC.....139
 - resume ACC follow mode.....137
 - resume ACC set speed.....137
 - using ACC.....134
 - warning lamp.....56
 - Curtain airbags.....45
- ## D
- DAB radio.....153
 - Data recording.....245
 - Daytime running lamps.....59
 - Declarations of conformity.....258
 - Deleting the connected phone or device.....162
 - Deselecting valet mode.....81

Index

- Detachable tow bar
 - fitting.....98
 - removing.....99
- Detection beam issues.....138
- Device pairing and connecting.....161
- Diesel
 - filler flap.....181
 - fuel.....180
 - glow plugs
 - warning lamp.....55
 - misfuel device.....181
 - sulphur content.....180
- Diesel particulate filter (DPF).....186
 - cold weather driving.....186
 - driving short distances.....186
 - sulphur content.....180
- Dimensions.....253
- Direction indicators.....58
 - warning lamp.....56
- Disability modifications
 - airbags.....46
- Disabling the passenger air bag.....43
- Door mirrors.....68
 - blind spot monitor
 - closing vehicle sensing.....72
 - sensors.....73
- Door transceiver
 - assistance.....76
 - erase all programming.....75
 - garage door opener.....74
 - programming.....74
 - programming a single button.....75
 - programming the garage door opener.....74
 - rolling code device programming.....75
- Double locking.....14
 - full alarm.....15
- Downloading from the internet
 - InControl connection.....166
- Drive away locking.....9
- Driver exit
 - deactivating intelligent stop/start.....111
- Drive selector
 - malfunction.....114
- Drive selector fails to elevate.....114
- Driving
 - ACC automatic switch-off.....136
 - ACC driving hints.....137
 - ACC emergency braking.....140
 - ACC follow mode.....135
 - ACC forward alert.....139
 - ACC gap change.....135
 - ACC malfunction.....138
 - ACC queue assist.....136
 - ACC radar detection beam issues.....138
 - ACC set speed and follow mode
 - override.....136
 - activating intelligent stop/start.....110
 - adaptive cruise control.....134
 - after a collision.....244
 - after deployment of the pedestrian protection system.....244
 - arduous conditions.....185
 - automatic braking.....119
 - automatic speed limiter.....132
 - before starting.....244
 - blind spot monitor
 - closing vehicle sensing.....72
 - blind spot monitor messages.....73
 - brake control with ABS.....118
 - brakes important information.....118
 - daily checks.....185
 - deactivating intelligent stop/start.....110
 - DSC active warning lamp.....54
 - electronic brake force distribution.....118
 - emergency brake assist.....118
 - forward alert.....139
 - forward alert warning lamp.....56
 - gear shift warning lamp.....56
 - lane departure warning lamp (green).....57
 - lane departure warning lamp (red).....54
 - low oil pressure.....53
 - park assist limitations.....128
 - park assist troubleshooting.....129
 - rain sensor.....65
 - resume ACC follow mode.....137
 - resume ACC set speed.....137
 - running-in.....185
 - selecting park assist.....127