

- Charging the vehicle battery.....208
 - Chassis number.....246
 - Child safety
 - booster seats.....39
 - check list.....39
 - child seats.....36
 - ISOFIX installation.....39
 - larger children on booster seats.....39
 - lock and window inhibitor.....36
 - positioning.....37
 - recommended child seats.....39
 - tether straps.....40
 - Cleaning
 - after off-road driving.....197
 - airbag covers.....199
 - alloy wheels.....198
 - exterior.....197
 - glass.....198
 - interior.....198
 - leather.....198
 - park assist sensors.....197
 - parking aids sensors.....197
 - rear screen.....198
 - seat belts.....199
 - sensors and cameras.....197
 - under body.....197
 - washer jets.....200
 - Climate control
 - air vents.....84
 - auto setting.....83
 - heated and cooled seats.....85
 - heated seats.....85
 - manual.....82
 - remote control batteries.....87
 - third row seats.....88
 - Climate seats.....85
 - Clock.....48
 - Closing the bonnet.....188
 - Closing vehicle sensing.....72
 - Clutch
 - fluid level.....204
 - Cold weather driving
 - diesel particulate filter (DPF).....186
 - Compatibility of phones.....161
 - Condensation (headlamps).....60
 - Conformity declarations.....258
 - Connecting a media device.....155
 - Connecting a phone or device.....161
 - Connecting jump leads.....207
 - Connecting multiple portable media devices.....158
 - Controls
 - touch screen.....79
 - Convenience mode.....9
 - Coolant
 - checking the level.....203
 - specification.....203
 - top up.....203
 - Courtesy delay.....59
 - Covers
 - refitting.....189
 - removal.....189
 - Critical warning messages.....53
 - Cruise control.....133
 - ACC driving hints.....137
 - ACC emergency braking.....140
 - ACC follow mode.....135
 - ACC gap change.....135
 - ACC radar detection beam issues.....138
 - ACC set speed and follow mode override.....136
 - adaptive cruise control.....134
 - adaptive cruise control malfunction.....138
 - follow mode.....135
 - forward alert in ACC.....139
 - resume ACC follow mode.....137
 - resume ACC set speed.....137
 - using ACC.....134
 - warning lamp.....56
 - Curtain airbags.....45
- ## D
- DAB radio.....153
 - Data recording.....245
 - Daytime running lamps.....59
 - Declarations of conformity.....258
 - Deleting the connected phone or device.....162
 - Deselecting valet mode.....81

Index

Detachable tow bar		
fitting.....	98	
removing.....	99	
Detection beam issues.....	138	
Device pairing and connecting.....	161	
Diesel		
filler flap.....	181	
fuel.....	180	
glow plugs		
warning lamp.....	55	
misfuel device.....	181	
sulphur content.....	180	
Diesel particulate filter (DPF).....	186	
cold weather driving.....	186	
driving short distances.....	186	
sulphur content.....	180	
Dimensions.....	253	
Direction indicators.....	58	
warning lamp.....	56	
Disability modifications		
airbags.....	46	
Disabling the passenger air bag.....	43	
Door mirrors.....	68	
blind spot monitor		
closing vehicle sensing.....	72	
sensors.....	73	
Door transceiver		
assistance.....	76	
erase all programming.....	75	
garage door opener.....	74	
programming.....	74	
programming a single button.....	75	
programming the garage door opener.....	74	
rolling code device programming.....	75	
Double locking.....	14	
full alarm.....	15	
Downloading from the internet		
InControl connection.....	166	
Drive away locking.....	9	
Driver exit		
deactivating intelligent stop/start.....	111	
Drive selector		
malfunction.....	114	
Drive selector fails to elevate.....	114	
Driving		
ACC automatic switch-off.....	136	
ACC driving hints.....	137	
ACC emergency braking.....	140	
ACC follow mode.....	135	
ACC forward alert.....	139	
ACC gap change.....	135	
ACC malfunction.....	138	
ACC queue assist.....	136	
ACC radar detection beam issues.....	138	
ACC set speed and follow mode		
override.....	136	
activating intelligent stop/start.....	110	
adaptive cruise control.....	134	
after a collision.....	244	
after deployment of the pedestrian protection		
system.....	244	
arduous conditions.....	185	
automatic braking.....	119	
automatic speed limiter.....	132	
before starting.....	244	
blind spot monitor		
closing vehicle sensing.....	72	
blind spot monitor messages.....	73	
brake control with ABS.....	118	
brakes important information.....	118	
daily checks.....	185	
deactivating intelligent stop/start.....	110	
DSC active warning lamp.....	54	
electronic brake force distribution.....	118	
emergency brake assist.....	118	
forward alert.....	139	
forward alert warning lamp.....	56	
gear shift warning lamp.....	56	
lane departure warning lamp (green).....	57	
lane departure warning lamp (red).....	54	
low oil pressure.....	53	
park assist limitations.....	128	
park assist troubleshooting.....	129	
rain sensor.....	65	
resume ACC follow mode.....	137	
resume ACC set speed.....	137	
running-in.....	185	
selecting park assist.....	127	