


DAB RADIO CONTROLS



E151973

⚠ In the interest of safety, only operate or adjust the system when it is safe to do so.

⚠ Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.

Note: DAB radio may not be available in all countries and reception will be dependent upon the broadcasting network.

Note: Some types of body-mounted accessories (e.g., external loadspace stowage devices) may affect the performance of this system.

Note: Some electronic equipment being used within the vehicle, or within close proximity to the vehicle, may affect the performance of this system (e.g., charging a device, etc.).

Press the Media menu button, or touch the Media menu soft key from the Touch screen **Home menu** and then select the **DAB Radio** soft key. See **85, TOUCH SCREEN HOME MENU**.

- 1. DAB 1/2/3:** Touch to view and select a DAB band (**DAB 1, 2, or 3**). The radio will tune to the last used channel on that band. Touch again to close.
- 2.** Display showing the current channel, the associated ensemble and relevant DAB radio text.
- 3. Seek down:**
 - Short touch to seek a previous available channel.
 - Long touch to seek the previous available ensemble. The first channel in the new ensemble will be selected.
- 4. Channel information:** Touch to view DAB text and channel information.
- 5. Seek up:**