

HYBRID SYSTEM WARNING MESSAGES

If the Critical warning message warning lamp (see **59, CRITICAL WARNING MESSAGE (RED)**), or the General warning/information message warning lamp (see **62, GENERAL WARNING/INFORMATION MESSAGE (AMBER)**) illuminate, and are accompanied by a Hybrid related message in the Message centre, follow the instructions shown in the table below.

Warning message	Warning	Action
Electric Drive only Performance and Drive Reduced	Critical warning message (red).	The vehicle can only be powered by the electric motor and has a limited range. Stop the vehicle when it is safe to do so. Contact a Retailer/Authorised Repairer.
Hybrid System and A/C Temporarily unavailable	General warning/information message (amber).	The vehicle can still be driven, but the Hybrid system and the Air Conditioning system will not operate. This is a temporary condition, so if no further warning messages appear, no action is required.
Hybrid Battery Fault	General warning/information message (amber).	The vehicle can still be driven, but the Hybrid system's functionality may be reduced. Contact a Retailer/Authorised Repairer as soon as possible.
High Voltage shut down not possible. System live	Critical warning message (red), and the Hybrid system battery fault warning lamp (see 60, HYBRID SYSTEM BATTERY FAULT (RED)).	The vehicle can still be driven. Contact a Retailer/Authorised Repairer as soon as possible.

Warning message	Warning	Action
Range Reduced	Critical warning message (red).	The vehicle will have a limited range, stop the vehicle in a safe location. Contact a Retailer/ Authorised Repairer.
Range Reduced. Hybrid Battery Too Cold ¹	Critical warning message (red).	Stop the vehicle in the nearest safe location. If possible, store the vehicle in a warmer area to rectify the vehicle's condition.

¹ Extreme cold climate conditions (circa -30°C) have an effect on the Hybrid's battery, limiting the vehicle's range.