1. From the **Nav menu**, select **Destination entry**.
2. Touch **Postcode**. Enter the postcode of your waypoint or destination from the keypad. The postcode must be entered precisely, including any spaces or punctuation.
3. When the postcode has been entered, touch **Ok**.

EMERGENCY

Note: *This facility is not available in all countries.*

1. From the **Nav menu**, touch **Destination entry**.
2. Touch **Emergency**, to display a list of local police stations, hospitals, or Land Rover Retailers.
3. Touch **Name** to display the list in alphabetical order, or **Distance** to display the list in order of proximity to the current vehicle location.
4. Touch the name of the facility to set it as a destination or waypoint.

MAP

Scroll the map to the area of your destination or waypoint, zooming in, if required.

This location can be stored as a favourite, destination, or waypoint.

COORDINATES

If you know the coordinates of your destination, they can be entered from this screen:

- From the **Nav menu**, select **Destination entry**.
- Select **More...**.
- Select **Coordinates**. The full latitude must be entered first before the longitude coordinates can be entered.
- Touch **Ok**, when the coordinates have been entered.

If the coordinates entered are not contained within the area covered by the available maps, a message will be shown. This can also occur if the incorrect coordinates have been entered.

RECALLING A PREVIOUS DESTINATION

1. From the **Nav menu**, touch **Previous destination**.
2. Touch your previous destination from the list. The map showing the selected destination is displayed.
3. Touch **GO** to start the journey.

MOTORWAY ENTRY/EXIT

1. From the **Nav menu**, touch **Destination entry**.
2. Touch **More...**.
3. Touch **Motorway Entry/Exit**.
4. Enter the motorway name or number, or select from **List**.
5. Touch **Entrance** or **Exit**.
6. Enter the entrance or exit name for the chosen motorway, or select from **List**. The map showing the selected motorway and junction is displayed.
7. Touch **GO** to start the journey.