


DAB RADIO CONTROLS



E151973

⚠ In the interest of safety, only operate or adjust the system when it is safe to do so.

⚠ Sustained exposure to high sound levels (greater than 85 decibels) can damage your hearing.

Note: DAB radio may not be available in all countries and reception will be dependent upon the broadcasting network.

Note: Some types of body-mounted accessories (e.g., external loadspace stowage devices) may affect the performance of this system.

Note: Some electronic equipment being used within the vehicle, or within close proximity to the vehicle, may affect the performance of this system (e.g., charging a device, etc.).

Press the Media menu button, or touch the Media menu soft key from the Touch screen **Home menu** and then select the **DAB Radio** soft key. See **84, TOUCH SCREEN HOME MENU**.

1. **DAB 1/2/3:** Touch to view and select a DAB band (**DAB 1, 2, or 3**). The radio will tune to the last used channel on that band. Touch again to close.
2. Display showing the current channel, the associated ensemble and relevant DAB radio text.
3. Seek down:
 - Short touch to seek a previous available channel.
 - Long touch to seek the previous available ensemble. The first channel in the new ensemble will be selected.
4. Channel information: Touch to view DAB text and channel information.
5. Seek up: