2. Touch the **Auto zoom** soft key. The soft key will be highlighted when Auto zoom is enabled.

Note: *The highest level to which the map will zoom out, is the scale value set before the Auto zoom feature is switched on.*

Note: *When the map's auto zoom feature is active, within approximately 8.8 km of the next guidance point, only a 2D or 3D heading up map will be displayed; outside of this distance, north up will be displayed, if this has previously been selected.*

SCREEN MODES

Touch the screen mode selection key to view a series of icons, each depicting a different screen mode (as detailed below). Touch the relevant icon to select the desired screen mode.



Full screen view.



Split screen view.



Shows a list of turn directions on the right half of the screen.



Guidance screen: Shows a detailed view of the next junction on the motorway or junction view on non-motorway roads, in the right half of the screen.



Motorway information: This view is available only when travelling on a motorway. It displays automatically to show the remaining motorway exits along your route, or all exits on the current motorway when the route is not set.

To switch off the Guidance screen or Motorway information screen, proceed as follows:

1. From the **Nav menu**, touch **More...**.
2. Select **Nav set-up**.
3. Touch **User settings**.
4. Touch **Guidance screen** or **Motorway information** to deselect the option.
5. Touch **Ok** to confirm.

SEARCH AREA

The navigation map database is divided into countries, or areas of countries, called search areas. When setting a route, the destination (or waypoint) entered must be in the currently selected search area.

Before attempting to set a destination or waypoint, set the correct search area, as follows:

1. From the **Nav menu**, touch **Destination entry**.
2. Touch **More...**.
3. Touch **Search area**.
4. Scroll through the list and select the 3 letter code that corresponds to the desired destination area.
5. Select **Ok**. The **Destination entry** menu is shown and the information window shows the currently selected search area.