1. Steering wheel menu control: Press **OK** to activate the menu, then use as follows:
   - Press the up/down arrows to scroll through a list.
   - Press the right arrow to view a sub-list.
   - Press the left arrow to return to the previous menu.
   - Press the **OK** button to select the highlighted menu item.
2. Scroll through the menu options as follows:
   - **Driver Assistance** menu.
   - **Trip Computer** menu.
   - **Display Settings** menu.
   - **Vehicle Settings** menu.

⚠ **Before making any changes to the Vehicle Settings, you must make sure that you have read and fully understood, the relevant topics/ sections of the Owner's Handbook. Failure to do so could lead to serious injury or death.**

   - **Vehicle Information** menu.

     Note: *Only available before the engine starts.*
   - **Head-Up Display (HUD)** menu.

WARNING AND INFORMATION MESSAGES

⚠ **Do not ignore warning messages, take appropriate action as soon as possible. Failure to do so may result in serious damage to the vehicle.**
If the message is suppressed, an amber or red warning icon will remain illuminated until the cause of the message is rectified.

For information regarding the individual messages, their meanings, and any action required, please refer to the relevant section within this handbook.

If more than 1 message is active, each is displayed in turn for 2 seconds, in order of priority.

Note: *Messages are displayed in order of importance. High importance warning messages are given the highest priority.*

Warning messages may be accompanied by an audible warning, and the message text may have the handbook symbol next to it. Warning messages are displayed until the condition causing the fault is rectified or the message is suppressed using the **OK** button on the steering wheel.

TRIP COMPUTER

The Trip computer memory stores data for a journey, or series of journeys, until it is reset to zero.

There are 3 trip memories available, **Trip A**, **Trip B** and **Trip Auto**. You can specify which trip memory is viewable, using the Instrument panel menu.